



SKU Print

Barcode program sheet for Socket CHS Scanners

Factory Reset


Configures the CHS to revert all settings to factory defaults. The CHS will power off after scanning this barcode. Scanner must be unpaired to complete this task. You may skip this task if a factory reset is not needed.



#FN800F0#

iOS Mode

Scan this barcode first to change the CHS to iOS mode.



Command Barcodes

Scan these four barcodes to program the CHS for scanning in Shopify for SKU Print.

